

# User Manual

簡易版

## LED ARC

---



deco

## 基本仕様

- 入力電圧 AC90-260V, 50/60Hz
- 消費電力 120W
- サイズ 100 × 193 × 37
- 重量 3Kg
- 光源 4W × 24粒, 4in1, RGBW
- 照射角 25°
- 制御モード 標準DMX512
- chモード 4/8
- IP 65
- 3PinDMX防水コネクタ IN/OUT
- その他の機能  
TILT角度調整用に手動で制御可能  
マスタースレーブ機能

deco

# 本体設定

## 設定方法



A ファンクションキー  
B アドレス設定

Aボタン 9つの機能を選択

Bボタン 数値値を変更

※データ入力がない場合は10秒後に保存されます。

No	Display	Function
1	001	8 c hモードのDMXアドレス設定 (001-512)
2	0.01	4 c hモードのDMXアドレス設定 (001-512)
3	C00	Color Jimping Change(01-99)
4	P00	Color Pulse Changing and Color Fading(01-99)
5	E00	Color Mixing(01-99)
6	R25	Red Deimmer
7	G25	Green Dimmer
8	B25	Blue Dimmer
9	W25	White Dimmer

# DMX PROTOCOL

## 4ch Mode

Channel	Function	Value	Descriptuon
1	Red	0-255	0-100% Red Dimmer from dark to bright
2	Green	0-255	0-100% Green Dimmer from dark to bright
3	Blue	0-255	0-100% Blue Dimmer from dark to bright
4	White	0-255	0-100% White Dimmer from dark to bright

## 8ch Mode

Channel	Function	Value	Descriptuon
1	Dimmer	0-255	0-100% Liner Dimmer from dark to bright
2	Strobe	0-255	Strobe effect from slow to fast
3	Effect	0-050	Other channels activated
		051-100	Color Jumping effect
		01-150	Color Fading effect
		151-200	Pulse color changing effect
		201-255	Sound control activated
4	Speed	0-255	Speed control of ch3 from slow to fast
5	Red	0-255	0-100% Red Dimmer from dark to bright
6	Green	0-255	0-100% Green Dimmer from dark to bright
7	Blue	0-255	0-100% Blue Dimmer from dark to bright
8	White	0-255	0-100% White Dimmer from dark to bright

deco