

User Manual

簡易版

EYEBEAM 1010F



deco

基本仕様

- ・ 入力電圧 90V-260V, 50/60Hz
- ・ 消費電力 155W
- ・ サイズ 260 × 480 × 480
- ・ 重量 13.82kg
- ・ 光源 10W × 10粒
4in1, RGBW
- ・ 照射角 5°
- ・ chモード 55/15/59
- ・ IP 20
- ・ 制御モード DMX512
Master-alone
Sound activated or Auto
- ・ 3PinDMX IN/OUT

deco

本体設定

【MENU】

DMX Address	A001-A512		
Auto Play	Auto Run	Master/Alone	
	Music Control	Master/Alone	
Reset	On/Off		
Reverse Pan	On/Off		
Reverse Tilt	On/Off		
Mic sensitivity	0-99%		
Special	Reset Default	On/Off	
	Calibration	Code(Password:088) PAN,TILT,Head1,Head2	
	Temperature	XXX°C/°F	
	Manual Control	PAN=XXX...	
	Signal Set	Wire DMX Wireless DMX Act WDMX&Out	
Edit Program	Program1	Steps(1..8)	
		Scenes 01	Pan=XXX...
	
		Scenes 08	Time=xx.xS
Mode of channel	Standerd Mode		
	Basic Mode		
	Extended Mode		

deco

DMX PROTOCOL

deco

Mode/Channel			Fancion	Values	Description
Standard Mode	Basic Mode	Extended Mode			
1	1	1	Pan	0-255	PAN Movement
1	1	1	Pan rotation	0-3	Pan rotation stop
				4-127	Forwards rotation from fast to slow
				128-131	Pan rotation stop
				132-255	Backwards rotation from slow to fast
2	-	2	Pan-fine	0-255	Fine control of Pan movement
3	2	3	Tilt	0-255	Tilt movement
3	2	3	Tilt rotation	0-3	Tilt rotation stop
				4-127	Forwards rotation from fast to slow
				128-131	Tilt rotation stop
				132-255	Backwards rotation from slow to fast
4	-	4	Tilt-fine	0-255	Fine control of Tilt movement
5	3	5	Head1	0-255	Head1 Movement
6	-	6	Head1-Fine	0-255	Fine control of Head1 movement
7	4	7	Head2	0-255	Head2 movement
8	-	8	Head2-Fine	0-255	Fine control of Head2 movement
9	5	9	Speed Pan/Tilt	0-225	Max to min speed
				226-235	backout by movement
				236-255	No function
10	6	10	Rotation	0-65	No function
				66-130	Pan rotation
				131-195	Tilt rotation
				196-255	Pan&Tilt rotation
11	7	11	Shutter	0-9	No function
				10-249	Strobe effect slow to fast
				250-255	No function
12	8	12	Dimmer	0-255	Dimmer0%...100%
-	9	13	Red	0-255	0-100% Red dimmer from dark to bright
-	10	14	Green	0-255	0-100% Green dimmer from dark to bright
-	11	15	Blue	0-255	0-100% Blue dimmer from dark to bright
-	12	16	White	0-255	0-100% White dimmer from dark to bright
13	-	17	Red in Pixel 1	0-255	Red in pixel 1 saturation contro (0-100%)
14	-	18	Green in Pixel 1	0-255	Green in pixel 1 saturation control (0-100%)
15	-	19	Blue in Pixel 1	0-255	Blue in pixel 1 saturation control (0-100%)
16	-	20	White in Pixel 1	0-255	White in pixel 1 saturation control (0-100%)
17	-	21	Red in Pixel 2	0-255	Red in pixel 2 saturation contro (0-100%)
18	-	22	Green in Pixel 2	0-255	Green in pixel 2 saturation control (0-100%)
19	-	23	Blue in Pixel 2	0-255	Blue in pixel 2 saturation control (0-100%)
20	-	24	White in Pixel 2	0-255	White in pixel 2 saturation control (0-100%)
21	-	25	Red in Pixel 3	0-255	Red in pixel 3 saturation control (0-100%)
22	-	26	Green in Pixel 3	0-255	Green in pixel 3 saturation cotrol (0-100%)
23	-	27	Blue in Pixel 3	0-255	Blue in pixel 3 saturation cotrol (0-100%)
24	-	28	White in Pixel 3	0-255	White in pixel 3 saturation cotrol (0-100%)
25	-	29	Red in Pixel 4	0-255	Red in pixel 4 saturation cotrol (0-100%)
26	-	30	Green in Pixel 4	0-255	Green in pixel 4 saturation cotrol (0-100%)
27	-	31	Blue in Pixel 4	0-255	Blue in pixel 4 saturation cotrol (0-100%)
28	-	32	White in Pixel 4	0-255	White in pixel 4 saturation cotrol (0-100%)
29	-	33	Red in Pixel 5	0-255	Red in pixel 5 saturation cotrol (0-100%)
30	-	34	Green in Pixel 5	0-255	Green in pixel 5 saturation cotrol (0-100%)
31	-	35	Blue in Pixel 5	0-255	Blue in pixel 5 saturation cotrol (0-100%)
32	-	36	White in Pixel 5	0-255	White in pixel 5 saturation cotrol (0-100%)
33	-	37	Red in Pixel 6	0-255	Red in pixel 6 saturation cotrol (0-100%)
34	-	38	Green in Pixel 6	0-255	Green in pixel 6 saturation cotrol (0-100%)
35	-	39	Blue in Pixel 6	0-255	Blue in pixel 6 saturation cotrol (0-100%)
36	-	40	White in Pixel 6	0-255	White in pixel 6 saturation cotrol (0-100%)

DMX PROTOCOL

deco

37	-	41	Red in Pixel 7	0-255	Red in pixel 7 saturation control (0-100%)
38	-	42	Green in Pixel 7	0-255	Green in pixel 7 saturation control (0-100%)
39	-	43	Blue in Pixel 7	0-255	Blue in pixel 7 saturation control (0-100%)
40	-	44	White in Pixel 7	0-255	White in pixel 7 saturation control (0-100%)
41	-	45	Red in Pixel 8	0-255	Red in pixel 8 saturation control (0-100%)
42	-	46	Green in Pixel 8	0-255	Green in pixel 8 saturation control (0-100%)
43	-	47	Blue in Pixel 8	0-255	Blue in pixel 8 saturation control (0-100%)
44	-	48	White in Pixel 8	0-255	White in pixel 8 saturation control (0-100%)
45	-	49	Red in Pixel 9	0-255	Red in pixel 9 saturation control (0-100%)
46	-	50	Green in Pixel 9	0-255	Green in pixel 9 saturation control (0-100%)
47	-	51	Blue in Pixel 9	0-255	Blue in pixel 9 saturation control (0-100%)
48	-	52	White in Pixel 9	0-255	White in pixel 9 saturation control (0-100%)
49	-	53	Red in Pixel 10	0-255	Red in pixel 10 saturation control (0-100%)
50	-	54	Green in Pixel 10	0-255	Green in pixel 10 saturation control (0-100%)
51	-	55	Blue in Pixel 10	0-255	Blue in pixel 10 saturation control (0-100%)
52	-	56	White in Pixel 10	0-255	White in pixel 10 saturation control (0-100%)
53	13	57	Pixel Macro	0-15	No function
				16-35	Macro 1 from slow to fast
				36-55	Macro 2 from slow to fast
				56-75	Macro 3 from slow to fast
				76-95	Macro 4 from slow to fast
				96-115	Macro 5 from slow to fast
				116-135	Macro 6 from slow to fast
				136-155	Macro 7 from slow to fast
				156-175	Macro 8 from slow to fast
				176-195	Macro 9 from slow to fast
				196-215	Macro 10 from slow to fast
				216-235	Macro 11 from slow to fast
236-255	Macro 12 from slow to fast				
54	14	58	Special function	0-19	No function
				20-29	No function
				30-39	No function
				40-79	No function
				80-99	Motor reset
				100-255	Internal program 1
55	15	59	Fixture ID Address Selection	0-9	No function
				10-19	Fixture ID 1
				20-29	Fixture ID 2
				30-39	Fixture ID 3
				40-49	Fixture ID 4
				50-59	Fixture ID 5
				60-69	Fixture ID 6
				70-79	Fixture ID 7
				80-89	Fixture ID 8
				90-99	Fixture ID 9
				100-109	Fixture ID 10
				110-119	Fixture ID 11
				120-129	Fixture ID 12
				130-139	Fixture ID 13
				140-149	Fixture ID 14
				150-159	Fixture ID 15
				160-169	Fixture ID 16
				170-179	Fixture ID 17
				180-189	Fixture ID 18
				190-199	Fixture ID 19
				200-209	Fixture ID 20
				210-219	Fixture ID 21
				220-229	Fixture ID 22
				230-239	Fixture ID 23
				240-249	Fixture ID 24
250-255	Fixture ID 25				